



Warning

- · Keep fingers away from hinges and joints
- · To be used for restrianing Soccer Balls only
- · Not a toy, do not climb on net
- · Must be used with adult supervision
- · Must be either Staked or Weighted down using BowBags (not supplied)
- · Don't drag. To move net, use two people .








2. Lift side of frame until hinge locks (clicking sound)



3. Repeat on other half of frame. All four hinge buttons must be locked.



1. Place double hinge on ground with net

spread out away from you. Open one half


4. Lay the frame on the ground with the rubber feet down and the four tubes up




5. Take 2 of the four Black Poles and slot them into the 2 rear tubes.




6. Feed the 2 remaining Poles down the Nets orange 'front posts' sleeves and slot them into the front tubes.



7. Next take the 2 front Net loops and place over the tops of the front Poles.



8. Repeat with rear loops holding Poles and Net firmly.



9. Finally take black Loops (A) and place under Rubber Feet. (B) Stake the Net on Grass or use Bowbags on Turf (not supplied)



SUMMIT SPORT - AUSTRALIAN DIST.

E: enquiries@summitsport.com.au

P: (07) 3889 8744 W: summitsport.com.au